

# DC inverter air to water heat pump monobloc Type

manual



Before operation this product, please read the instructions carefully and save this manual for future.

Thank you for choosing our quality product.

Please read this manual carefully before use and follow the instructions to operate the unit in order to prevent damages on the device or injuries to staff.

Specifications are subject to change with product improvements without prior notice. Please refer to the specification sticker on the unit for upgraded specifications.

**Heat pump consists of :**

- \* **compressor : DC inverter compressor complete with thermal protection and crankcase heating element.**
- \* **electronic expansion valve**
- \* **water-side heat exchanger complete with water-flow-switch.**
- \* **air-side heat exchanger with copper pipes and aluminium fins, complete with grid protection.**
- \* **axial fan**
- \* **outdoor temperature probe for control and climatic compensation of the water set point ( heat curve ).**
- \* **structure in painted galvanised steel complete with condensation tray.**
- \* **electronic control panel equipped with electrical terminal boards for connective external consents.**
- \* **LCD controller with thermostat function, displaying and setting the operating parameters.**

**Heat pumps stand out for their compactness and high performances : operation down to -20'c and COP up to 4.2 at A+7/W+35'c. They are reversible and can be used for heating and for cooling in summer. They can also be used for fan coil units.**

**They are composed of an outside unit, which is connected to indoor module by copper connective pipe.**

**The inside module comes fully equipped and includes, in particular :**

- **a control panel that can be programmed according to the outside temperature that communicates with the unit and, depending on the options connected, can be used to manage a direct heating circuit**
- **circulation pump**
- **auxiliary heating**
- **3-way-water-valve : the motorised reversal valve with connector for sanitary hot water tank**

**Optional accessory :**

- **buffer tank : used to limit operation of the compressor in short cycles and to provide a reserve for the defrosting phase on reversible air/water heat pump.**

**■ Working temperature range:**

- **in heating mode :**
  - outside air : -20 ~55°C**
  - water : +18/+55'c**
- **in cooling mode :**
  - outside air : +15 ~42°C**
  - water : +7/+25'c**

**Maximum operating water pressure : 7bar.**

**When install the unit, be sure to check whether the selection of installation place, power supply specifications, usage limitation(power supply voltage and etc.) and installation spaces**

# Content

# 1 Safety precautions

## IMPORTANT

If heat pump is not running in the winter, it is necessary to keep power supply connected for Anti-freeze protection. In cold weather ( $\leq 0^{\circ}\text{C}$ ), if heat pump is no longer needed, do drain out all the water inside the system.

### 1.1 Safety precautions



- warning




- suggestion




- prohibition

Once abnormality like burning smell occurs, please cut off the power supply immediately and then contact with service center.



If the abnormality still exists, the unit may be damaged and electric shock or fire may result.

Be sure to pull out the power plug and drain the indoor unit and water tank when unit is not in use for a long time.



Otherwise, the accumulated dust may cause overheating fire or freeze of water tank or coaxial heater exchanger in winter.

Special circuit must be adopted for power supply to prevent fire.



Do not use octopus multipurpose plug or mobile terminal board for wire connection.

Before installation, please see if the voltage of local place accords with that on nameplate of unit and capacity of power supply, power cord or socket is suitable for input power of this unit.



Don't operate the unit with wet hand.




Otherwise, it may cause electric shock.

Never damage the electric wire or use the one which is not specified.



Otherwise, it may cause Overheating or fire.

Before cleaning please cut off the power supply. Otherwise, it may cause electric shock or damage.












The power supply must adopt special circuit with leakage switch and enough capacity.

It is mandatory to use a suitable circuit-breaker for the heat pump and make sure the power supply to the heater corresponds to the specifications. Otherwise the unit might be damaged.



User can not change power cord socket without prior consent. Wiring working must be done by professionals. Ensure good earthing and don't change earthing mode of unit.

<p><b>Earthing: the unit must be earthed reliably !</b> The earthing wire should connect with special device of buildings.</p>  <p>If not, please ask the qualified personnel to install. Furthermore, don't connect earth wire to gas pipe, water pipe, drainage pipe or any other improper places which professional does not recognize.</p>	<p><b>Never insert any foreign matter into unit to avoid damage . And never insert your hands into the air outlet of unit.</b></p> 	<p><b>Don't attempt to repair the unit by yourself.</b></p>  <p>Improper repair may cause electric shock or fire, so you should contact the service center to repair.</p>
<p><b>Don't step on the top of the unit or place anything on it.</b></p>  <p>There is the danger of fall of things or people.</p>	<p><b>Never block the air inlet and outlet of unit.</b></p>  <p>It may reduce efficiency or cause stop of the unit and even fire.</p>	<p><b>Keep pressurized spray ,gas holder and so on away from the unit above 1m . It may cause fire or explosion.</b></p> 
<p><b>Please note whether the installation stand is firm enough or not.</b></p>  <p>If damaged, it may cause fall of the unit and injury of people.</p>	<p><b>Make sure to use a dedicated power line for the heat pump only. Do not add other appliances to the line.</b></p> 	<p><b>Make sure no water or other liquid drips into the electric box of the unit Otherwise the unit might be damaged.</b></p> 

## 2 Working principle of a Heat Pump (refrigerant circuit) :

The refrigerant system consists of 6 main components :

DC inverter type compressor, 4-way-valve, heat exchanger(condenser, refrigerant to water),  
electronic expansion valve, evaporator(air to refrigerant).

Heat pump can absorb the heating from air source. This makes the heat pump a very environmentally friendly and economically sound alternative for space heating.


\* evaporator ( air coil ) : low temperature, low pressure refrigerant go through evaporator, to boil and turn from liquid to gas.

\* compressor: compressor absorb refrigerant, and compress to high temperature, high pressure status.

\* condenser: refrigerant release heat energy to heat exchanger. refrigerant temperature reduce, and it return from gas status to liquid status.


The heat energy is absorbed by water, circulated by a circulation pump to indoor radiator or floor heating systems.

\* EEV: at last the refrigerant go through the electronic expansion valve, where its pressure is reduced, and then continues to the evaporator.



# 3 Explored view

## 3.1 explored view



1	<b>Back net</b>	12	Separate panel	23	<b>Power board</b>
2	Bottom plate	13	<b>Electronic control box</b>	24	4-way-valve
3	<b>Evaporator</b>	14	<b>Cover</b>	25	<b>High/Low pressure protection</b>
4	Top panel	15	<b>Terminal</b>	26	Electronic expansion valve
5	Evaporator bottom heater	16	Reactance	27	<b>Service vial</b>
6	Motor bracket	17	Motor capacitor	28	<b>Circulation pump</b>
7	Motor	18	<b>Wire controller</b>	29	<b>Heat exchanger</b>
8	Fan blade	19	SPM module	30	<b>Receiver</b>
9	<b>Front panel</b>	20	<b>Cable clip</b>	31	Compressor heater
10	Front net	21	Main circuit board	32	Compressor
11	<b>Service panel</b>	22	<b>Transition circuit board</b>	33	Right panel




### 3.2 main components



compressor



Shell tube heat exchanger



evaporator



Pressure switch



Electronic expansion valve



4-way-valve



Fan blade



Motor



sensor



3-way-water-valve



Circulation pump



Water flow switch



Electrical heater and holder



### 3.3 Circuit board for single phase



Wire controller, display panel



Main circuit board



SPM module



Transition circuit board - A



Transition circuit board - B

### 3.4 Circuit board for three phase



Wire controller, display panel



Main circuit board



SPM module



Transition circuit board - A



Transition circuit board - B



reactance




Power board

# 4. Applications


## 4.1 application 1: supply sanitary hot water, house heating

- 1 evaporator
- 2 defrost sensor
- 3 ambient temperature sensor
- 4 compressor
- 5 fan
- 6 electronic expansion valve
- 7 outlet water sensor
- 8 heat exchanger
- 9 inlet water sensor
- 10 circulation pump
- 11 electrical heater backup
- 12 three-way-water-valve
- 13 room temperature sensor
- 14 buffer tank
- 15 sanitary hot water tank
- 16 water sensor



# 5. Installation

## 5.1 installation plan



## 5.2 Installation Heat Pump Unit

### 5.1.1 Select the Installation Place of Unit

\* The unit should be installed on a solid wall and fastened securely.

\* The unit should be installed close to the house, on a terrace, on the façade or in a garden. They are designed to operate in the rain but can also be installed under cover as long as there is sufficient ventilation. There should be no obstacles to hinder the free circulation of air to the exchanger inlet and outlet (see installation diagrams below).

\* The emplacement of the unit should be carefully chosen and protected from prevailing winds in order for it to be compatible with environmental requirements: integration into the site, noise level.

\* We particularly recommend:

- Not placing the unit close to sleeping areas
- Not placing it opposite a glazed wall
- Avoiding proximity to a terrace


\* Moreover, we recommend positioning the unit above the average depth of snowfall in the region in which it is installed.

\* It is necessary to provide clearance all around the appliance to carry out connection, commissioning and maintenance operations.

\* The following procedure must be observed before connecting the pipes or electric cables.

- 1) decide which is the best position on the wall and leave enough space to be able to carry out maintenance easily.
- 2) fasten the unit support to the wall using screw anchors which are particularly suited to that type of wall.
- 3) use a larger quantity of screw anchors than normally required for the weight they have to bear: during operation the machine vibrates and has to remain fastened in the same position for years without the screws becoming loose.
- 4) mount the unit on the support using the four bolts supplied.


\* Please install the drain connector to the unit when necessary. In some cold areas (temperature below 0), please don't use the drain connector, otherwise it may clogged by ice.



## 5.4 Room temperature sensor installation

When customer choose fan coil mode, he should install the room temperature temperature sensor as following :

1. take the room temperature sensor out from the indoor unit.



2. Distance between the indoor unit and the remote room temperature sensor should be less than 15 meter due to length of the connection cable of remote air temperature sensor.

3. Height from floor is approximately 1.5 meter;

4. Remote room temperature sensor can not be located where the area may be hidden when door is open;

5. Remote room temperature sensor can not be located where external thermal influence may be applied;

6. Remote room temperature sensor should be installed where space heating is mainly applied;

## 5.6 Electrical connection



The electrical installation of heat pumps must be done in accordance with the local and national Codes of Practice and pursuant to prevailing standards, decrees and subsequent texts. The cable will be carefully chosen according to the following information: maximum amperage on the unit (thermodynamic unit). See the table below, distance of the appliance from the original power supply, upstream protection, neutral operating conditions.

Recommended cable cross-sections and circuit breakers to be installed:

Heat pump	Type	Output Electrical Absorbed kW	Intensity Nominal A	Max Intensity A	Power supply		Cable BUS SC : mm <sup>2</sup>
					SC : mm <sup>2</sup>	DJ	
5kW	Single	1.7	8	12	3x2		
7kW	Single	2.4	11	17	3x2.4		
9kW	Single	3	14	21	3x4		
12kW	Three	4	7	10.5			
15kW	Three	5	8.7	13			
18kW	three	6	10.5	15.8			

Electrical back-up

Single phase :	SC	3 x 6mm <sup>2</sup>
	DJ	

SC = cable cross-section in mm<sup>2</sup>

DJ = circuit breaker

1. It is recommended to use a suitable breaker for the heat pump and make sure the power supply to the heater corresponds to these specifications. Otherwise the unit might be damaged.
2. The power supply to the heat pump unit must be grounded.
3. Cable should be fixed tightly, to ensure it won't get loose.

## 5.7 Hydraulic connection

### 5.7.1 General

Pipe installation must be carried out in accordance with current norms and directives. Heat pump can operate with a return temperature of up to 50°C and an outgoing temperature from the unit of 55°C.

Heat pump is not equipped with shut off valves ; these must be installed outside the heat pump to facilitate any future servicing.

Heat pump can be connected to the radiator system, floor heating system and/or fan coil units.

Install the safety valve and manometer.

Heat Pump Unit is equipped with circulation pump, water-flow-switch, 3-way-water-valve, electrical heater backup, compressor, heat exchanger.

Note : take care of water freeze when ambient temperature is low than 3°C.

Buffer tank :



The installation of buffer tank is recommended for installations.

It is intended :


- increase the water volume in an installation in order to limit the short-cycle operation of the compressor. The greater the water volume, the lower the number of start-ups of the compressor and the longer its useful life.
- Guarantee on energy reserve for the defrosting phases.

Example of heat pump installations


- heat pump split compact
- DHW production by independent tank
- Buffer tank for house heating

### 5.7.2 Filling and venting the heating medium system


1. Check the water system for leakage.
2. Connect the filling pump and return line on the heating system's service connections as shown in figure.
3. Close the valve between the service connections.
4. Open the valves on the service connections(AV1,AV2).
5. Pushing the white manual lever down to bottom. (this has already been done when the machine leaves factory), then three way valve's water tank port is closed (the "B" port), room heat port is open (the "A" port).
6. Start the filling pump, and fill until there is fluid in the return pipe.
7. Open up Power ON from control panel to start machine, then heat medium water pump is running, the valve will return to the up position when power is restored.
8. Firmly pushing the white manual lever down to midway and in. in this position both the 'A' and 'B' ports are open.
9. The filling pump and the heating medium pump are now operational. The fluid should circulate via the container with tap water until it emerges from the return hose without being mixed with air.
10. Stop machine, heat medium water pump stop running. Depressing the white manual lever lightly and then pulling the lever out, pushing the while manual lever down to bottom position, and then "A" port open, "B" port is closed.
11. Stop the filling pump and clean the particle filter.
12. Start the filling pump, open the valve between the service connections.
13. Close the valve on the service connection's return line. Now pressurise the system (to max 3 bar)with the filling pump.
14. Close the valve (AV2) on the service connection.
15. Stop the filling pump.
16. Select the auto operating mode using the operating mode button.



Push the white gear onto the position of middle, and then use your thumb to press it inside, this time both port A and port B are in open state.




Please use screwdriver to unclench the white gear of the three way valve.



Then the white gear will move back to the original position. The three way valve will turn to port B automatically.




A mesh filter must be installed in front of the water inlet of the unit and water tank, for keeping the water quality and collecting impurity contained in the water. Take care to keep the water filter mesh towards the bottom. Check valve is recommended to be installed at both sides of the filter, so as to clean or change the filter in a easier way.



### 5.74 Circulation pump capacity diagram on heating medium side


5kW, 7kW

Available pressure




9kW, 12kW

Available pressure



15kW, 18kW

Available pressure



### Adjust water flow

WILO RS-25/6

Circulation pump adjust water flow: 1,2, 3 step



WILO RS-25/8

Circulation pump adjust water flow: 1,2, 3 step



WILO RL-25/7.5

Circulation pump adjust water flow: 1,2, 3 step



# 6 Control panel

## 6.1 description of display panel



water cooling mode



clock/timer/function display



water heating mode



clock



water tank heating mode



timer on



auto mode



timer off



water tank temperature status



temperature / function display



degree celsius



room heating/cooling mode



function setting



electric heater



compressor



outer fan motor





water pump




key lock

## 6.2 Key Lock function

When  is on, press  button for 5 seconds to release keylock.



If the unit receives no signal for 30 seconds, it will lock the key.

## 6.3 Starting Operation




Press  button, and the unit receives the signal, it gives out one " beep " tone , the operation is ON and the heat pump starts operation.



If the interval shorter than 3 minutes from last shut down to the present switch-on, the compressor only restarts after 3 minutes to protect the system.

## 6.4 Setting target temperature of water tank heating mode



Under running, Press the button  or  for increasing or decreasing the target temperature of water tank, setting range ( 20 ° C - 65 ° C ), default is 45 ° C .


## 6.5 clock Setting

Press 5 seconds  , the  flash, the right display ( = the minutes ) flash 




Press the button  or  for increasing or decreasing the minutes.



Press again  , the left display ( = the hour ) flash 



Press the button  or  for increasing or decreasing the hour.



Validate in pressing on  ( or wait 10 seconds ; the display will leave this setting mode by itself ).






## 6.6 TIMER Setting


Press  lightly,  flash, the left display ( = the hour ) flash 



Press button  or  for increasing or decreasing the hour.

Press again  , the right display ( = the minutes ) lights 





Press button  or  for increasing or decreasing the minutes.


Then, press  again,  flash, the left display (= the hour) flash , Press the button  or  for increasing or decreasing the hour.

Press again , the right display (= the minutes) lights 

Press the button  or  for increasing or decreasing the minutes.

## 6.7 Parameter setting

Press  to enter parameter setting, then button  and  to change the value of each setting, and press  again to enter the next Parameter setting (from P1 to P21).

Press  for 3 seconds to exit the setting. If you do not press any button, the system will save the setting automatically after 3 minutes.

Next time when you enter the Parameter setting, it will display the interface of the last setting. (Memory function).

P01 : Water tank temperature setting : range ( 20°C - 65°C ), default is 45°C

P02 : Room heat mode: 0 is floor heating, 1 is radiator, 2 is fan coil

P03 : Room and floor temperature setting :

A : when P2 is floor heating ( 0 ), then P03 range ( 20°C - 45°C ), default is 35°C.

Setting return water temperature is fixed.

B : when P2 is radiator ( 1 ), return water temperature will change according to ambient temperature

→ heat curve, choose gear or parameter P9.

\* gear range from 1 to 5 adjustable, default is gear 3.

C : when P2 is fan coil ( 2 ), room temperature reach setting temperature (parameter 5), compressor stop.

P04 : electric heater start temperature in water tank heating mode: range (30°C to 60°C adjustable), default is 60°C.

P05 : room setting temperature in fan coil mode: range (18°C to 32°C adjustable), default is 27°C.

P06 : minimum temperature difference of compressor start in water heating mode : 3°C to 15°C adjustable, default is 5°C.

P07 : minimum temperature difference of compressor start in room heating mode: 3°C to 15°C adjustable, default is 5°C.

P08 : maximum water outlet temperature in floor heating ( MAX . TEMP. ) : 25°C to 70°C adjustable, default is 45°C.

P09 : gear of room heat at radiator : gear range form 30°C to 70°C adjustable, default is 30°C.

P10 : electric heater mode selection in water tank heating mode:

0 is operate by parameter P04 ;

1 is electrical heater switch ON when water tank temperature reduce, and switch OFF when water tank temperature reach to setting temperature.

P11 : electric heater in floor heating, radiator: auto ( 0 ), off ( 1 ), default ( 1 ).

P12: minimum temperature difference of compressor lower frequency for constant temperature :

0°C to 6°C adjustable, default is 2°C.

P13 : heat pump stop when ambient temperature drop down to -25°C : range ( -25°C to -1°C adjustable ), default is -25°C.

P14 : heat pump start when ambient temperature increase to -20°C : range ( -20°C ~ 0°C adjustable ), default is -20°C.

P14 is 1°C more than P13 on setting.


P15 : anti-freeze protection: on ( 1 ), off ( 0 ), default ( 0 ).

P16 : Room cooling setting water temperature : range ( 5 °C - 35 °C adjustable ), default is 10 °C .




P17 : defrosting mode : auto defrosting ( 0 ), manual defrosting ( 1 )

P18 : defrosting start temperature : range ( -15°C ~ +2°C adjustable ), default is -4°C.  
 P19 : defrosting period : range ( 25 ~ 70 minutes adjustable ), default is 30 minutes  
 P20 : defrosting time : range ( 2 ~ 20 minutes adjustable ), default is 15 minutes.  
 P21 : defrosting exit temperature : range ( 8 ~ 20°C adjustable ), default is 12 minutes.




## 6.8 Mode setting

Press  to enter MODE setting : ( AUTO mode is available on some heat pumps )


### 6.8.1 AUTO1 mode:

When  switches on, heat pump is running in AUTO 1 mode,  and  is on.

### 6.8.2 AUTO2 mode:

When  switches on, heat pump is running in the AUTO 2 mode,  and  is on.

### 6.8.3 WATER TANK HEATING mode:

When  switches on, heat pump is running in the WATER TANK HEATING mode.


When water tank temperature reach target temperature,  switches on, otherwise,  switches on.

parameter setting as following:

- \* parameter P1 ( water tank setting temperature ) : temperature range ( 20 °C - 65 °C ), default is 45 °C
- \* parameter P6 ( minimum temperature difference of compressor start in water heating mode ) :  
3°C to 15°C adjustable, default is 5°C .

**Heat pump stop when water tank temperature reach to 45 °C (parameter P1), and heat pump restart when water tank drop down to 40 °C (parameter P1 – parameter P6 ).**

### 6.8.4 ROOM-HEATING mode:

When  switches on, heat pump is running in the ROOM - HEATING mode.

HEATING mode has 3 operations :

- 1) floor heating ( setting return water temperature is fixed )

parameter setting as following:

- \* P2 ( heating operation selection ) : 0
- \* P3 ( setting return water temperature ) : 20°C - 45°C adjustable, default is 35°C.
- \* P7 ( minimum temperature difference of compressor start in room heating mode ) :  
3°C to 15°C adjustable, default is 5° C .
- \* P8 ( maximum water outlet temperature ( MAX . TEMP. ) ) : 25°C to 65°C adjustable, default is 45° C .

Heat pump start when return water temp.  $\leq$  setting return temp. (parameter P3) – temp. different ( parameter P7).

Heat pump stop when return water temp.  $>$  setting return temp.

### Outlet water over-heat protection:

When outlet water temperature  $>$  parameter P8, compressor stop, electrical heater stop.

When outlet water temperature  $<$  P8 - 3°C, exit protection.

2) radiator ( heat curve : return water temperature will change according to ambient temperature ):

parameter setting as following:

\* P2 ( heating operation selection ) :

1

\* P3 ( gear ) :

gear range from 1 to 5 adjustable, default is gear 3

1st gear P9=20°C

2nd gear P9=30°C

3rd gear P9=40°C

4th gear P9=50°C


5th gear P9=60°C

\* P9 (P9 value is return water setting temperature when the ambient temperature is 0°C)

\* P7 ( minimum temperature difference of compressor start in room heating mode ):

3°C to 15°C adjustable, default is 5°C .

\* P8 ( maximum water outlet temperature ( MAX . TEMP. )): 25°C to 65°C adjustable, default is 45°C .



Tout = outdoor ambient temperature

Ts = setting return water temperature ( max. Ts = 70°C )

P9 value is return water setting temperature when the ambient temperature is 0°C

**Calculation :**

$$Ts = (P9 - 30) * (24 - Tout) / 24 + 30$$

\* Ts change every 5 minutes.


For example : parameter P9 is 40°C, now change to 48°C.

P9 increase from 40°C to 48°C.

When ambient = -5°C

if P9 = 40°C, return is 46°C

if P9 = 48°C, return is 56°C (but it is too high for heat pump)





(1) start condition : when ambient temperature  $< 23^{\circ}\text{C}$ , heat pump can run at radiator mode.

When ambient temperature  $> 25^{\circ}\text{C}$ , heat pump stop.

(2) Heat pump start when return water temp.  $\leq$  setting return temp. ( $T_s$ ) – temp. different ( parameter P7).

Heat pump stop when return water temp.  $> T_s + 1^{\circ}\text{C}$ .

\*  $T_s$  ( return water temperature ) is calculated by heat curve.

3) fan coil ( heat pump ON/OFF by room temperature ):

parameter setting as following:

\* P2 ( heating operation selection ): 3


\* P5 ( room setting temperature ) :  $18^{\circ}\text{C}$  to  $32^{\circ}\text{C}$  adjustable, default is  $27^{\circ}\text{C}$  .

\* P7 ( minimum temperature difference of compressor start in room heating mode ):  
 $3^{\circ}\text{C}$  to  $15^{\circ}\text{C}$  adjustable, default is  $5^{\circ}\text{C}$  .

Heat pump stop when room temperature  $>$  setting temperature (parameter P5)  $+ 1^{\circ}\text{C}$  .

Heat pump start when room temperature  $<$  setting temperature (parameter P5)  $- 1.5^{\circ}\text{C}$  .

### 6.8.5 ROOM-COOLING mode (optional):

When  switches on , heat pump is running in the ROOM - COOLING mode.

Parameter setting as following :

\* parameter P16 ( setting outlet temperature ) : range from  $5^{\circ}\text{C}$  to  $35^{\circ}\text{C}$  adjustable, default is  $10^{\circ}\text{C}$  .

#### constant temperature control

##### \* Enter condition :

After heat pump start, outlet temperature – setting outlet temperature  $\leq 2^{\circ}\text{C}$  (parameter 12), enter constant temperature control, or frequency select by [table 2-1](#).

\* Max frequency select by relative step on [table 2-1](#).

According to [draw 3-1](#), record  $\Delta T = T_1 - T_s + 2^{\circ}\text{C}$ ,  $\Delta T$  has 10 areas ( from 0 to 9 ), frequency change according to following:

a) when  $\Delta T$  change to other area

i) if  $\Delta T$  increase, frequency increase to next step ([table 3-1](#)) ; max step is relative Hz on [table 2-1](#).

If step already reach to max step, frequency would not increase any more although  $\Delta T$  increase to next area.

ii) if  $\Delta T$  reduce, frequency reduce to next step ;

if current frequency is  $F_1$ , frequency would not reduce any more although  $\Delta T$  reduce to next area.

b) when  $\Delta T$  keep at the same area 3 minutes, frequency change as following :

4~8: frequency increase to next step ([table 3-1](#)), and increase to next step every 10 minutes.

Till running frequency reach relative Hz on [table 2-1](#).


3 : frequency no change.

0~2: frequency reduce to next step ([table 3-1](#)), till running frequency reach  $F_1$ .

##### \* constant temperature area drawing :

$T_1$  : return water temperature ;  $T_s$  : setting return water temperature.

[Draw 3-1](#)



\* relation table between temperature area and compressor frequency ( HZ ) in non-constant temperature control

Table 2-1

Water temperature	< 19°C	19°C ~ 35°C	35°C ~ 45°C	> 45°C
Outdoor ambient temperature				
ambient temperature < 27°C	F6	F7	F6	F5
28°C ≤ ambient temperature ≤ 37°C	F9	F8	F7	F5
38°C ≤ ambient temperature ≤ 45°C	F8	F7	F4	F4
water temperature > 46°C	F6	F5	F4	F3

### 6.8.6 water tank heating + room heating / cooling:

Select water tank heating mode and room heating mode at the same time. Water tank heating is priority. When water tank temperature reaches to setting temperature, 3-way-water-valve change water flow to room heating/cooling automatically ; if water tank temperature drop down, 3-way-water-valve go back to water tank heating.

## 6.9 constant temperature control ( available on floor heating, radiator )

### 6.9.1 start condition :

Parameter setting as following :

P12: minimum temperature difference of compressor lower frequency for constant temperature :  
 0°C to 6°C adjustable, default is 2°C .

Heat pump start, if setting return water temperature – return water temperature ≤ 2°C (parameter 12) and electrical heater stop, then enter constant temperature control ; or frequency Hz control by [table 2](#).

### 6.9.2

Max frequency select by relative step on [table 2](#).

According to [draw 3](#), record  $\Delta T = T_1 - T_s + 2^\circ\text{C}$ ,  $\Delta T$  has 10 areas ( from 0 to 9 ), frequency change according to following:

a) when  $\Delta T$  change to other area

i) if  $\Delta T$  increase, frequency increase to next step ([table 3](#)) ; max step is relative Hz on [table 2](#).

If step already reach to max step, frequency would not increase any more although  $\Delta T$  increase to next area.

ii) if  $\Delta T$  reduce, frequency reduce to next step ;

if current frequency is  $F_1$ , frequency would not reduce any more although  $\Delta T$  reduce to next area.

b) when  $\Delta T$  keep at the same area 3 minutes, frequency change as following :

4-8: frequency increase to next step (**table 3**), and increase to next step every 10 minutes.

Till running frequency reach relative Hz on **table 2**.


3 : frequency no change.

0-2: frequency reduce to next step (table 3), till running frequency reach  $F_1$ .

### 6.9.3 constant temperature area drawing :

$T_1$  : return water temperature ;  $T_s$  : setting return water temperature.

#### Draw 3



### 6.9.4 relation table between temperature area and compressor frequency ( HZ ) in non-constant temperature control

Table 2

Outdoor ambient temperature	< 0°C	0°C ~ 10°C	10°C ~ 25°C	> 26°C
Water temperature				
Water temperature < 40°C	F10	F9	F8	F7
41°C ≤ water temperature ≤ 45°C	F9	F8	F7	F6
46°C ≤ water temperature ≤ 50°C	F8	F7	F6	F5
51°C ≤ water temperature ≤ 55°C	F7	F6	F5	F4
56°C ≤ water temperature ≤ 60°C	F6	F5	F4	F3
61°C ≤ water temperature ≤ 65°C	F5	F4	F3	F2

#### Relation table of F1 ~ F10 frequency ( Hz )

Table 3 ( factory will design Hz )

Step	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10
Frequency Hz										

## 6.10 electrical heater:

### 6.10.1 In water tank heating mode :

Parameter setting :

P04 : electric heater start temperature: temperature range from 30°C to 60°C adjustable, default is 60°C .

P10 : electric heater mode selection: 0 is operate by parameter P04 ; 1 is electrical heater switch ON when water tank temperature reduce, and switch OFF when water tank temperature reach to setting temperature.

(1) P10 = 0

For example, P01 = 55°C , P04 = 40°C, P10 = 0 ; compressor heat water tank to 40°C, then electrical heater switch ON. Compressor and electrical heater stop when water tank temperature = 55°C.

Or water tank temperature  $\leq 39^\circ\text{C}$ , electrical heater switch OFF.

(2) P10 = 1

For example, P01 = 55°C , P04 = 40°C, P10 = 1 ; compressor run, and electrical heater switch ON 3 minutes later.

Compressor and electrical heater stop when water tank temperature = 55°C. Then heat pump set P10 = 0.

Electrical heater only run one time, you have set P10 = 1 again for next operation.

(3) electrical heater switch ON forcibly during defrosting.

(4) CSP protection :

**Refrigerant system install 2 high pressure protection ( 40bar, 44bar ), 1 low pressure protection ( 0.7bar ).**

**40bar high pressure protection is for CSP protection.**

**When water tank temperature  $> 50^\circ\text{C}$** , compressor stop, circulation pump continuously run, electrical heater switch ON forcibly one time, enter CSP protection. 40bar high protection resume 3 minutes later.

Heat pump will record the highest water tank temperature, if highest water tank temperature - water

temperature  $\leq 3^\circ\text{C}$ , or if water tank temperature  $< 50^\circ\text{C}$ , then compressor start, and cancel CSP protection.

### 6.10.2 In floor heating, radiator mode :

Parameter setting :

P11 : electric heater in floor heating, radiator: auto ( 0 ), off ( 1 ), default ( 1 ) .

(1) P11 = 0, auto

When compressor run, electrical heater check return water temperature 15 minutes later.

If return water temperature do not increase  $1^\circ\text{C}$  every 5 minutes, electrical heater switch ON,

when return water temperature  $\geq T_{\text{set}} - 1^\circ\text{C}$ , electrical heater switch OFF, compressor still run.

Afterwards electrical heater would not wait 15 minutes any more, if return water temperature  $< T_{\text{set}} - 3^\circ\text{C}$ ,

and return water temperature do not increase  $1^\circ\text{C}$  every 5 minutes, then electrical heater switch ON.

If return water temperature -  $T_{\text{set}} \leq 2^\circ\text{C}$  ( parameter P13 ), electrical heater switch OFF.

(2) P11 = 1, off

Electrical heater switch OFF, only switch ON in some forcibly case.

(3) electrical heater switch ON forcibly during defrosting.

(4) CSP protection :

**When return water temperature  $> 50^\circ\text{C}$** , compressor stop, circulation pump continuously run, electrical heater switch ON forcibly one time, enter CSP protection. 40bar high protection resume 3 minutes later.

Heat pump will record the highest return water temperature, if highest return water temperature - water

temperature  $\leq 3^\circ\text{C}$ , or if return water temperature  $< 50^\circ\text{C}$ , then compressor start, and cancel CSP protection.

(5) in floor heating mode, outlet water temperature  $\geq 45^\circ\text{C}$  (parameter P8), electrical heater switch OFF forcibly.

## 6.11 compressor heater:

When outdoor ambient temperature  $< 0^\circ\text{C}$ , and compressor stop, then compressor heater switch ON.



When outdoor ambient temperature  $> 2^\circ\text{C}$ , or compressor start, then compressor heater switch OFF.

## 6.12 evaporator bottom heater:

When outdoor ambient temperature  $< 0^{\circ}\text{C}$ , and compressor start, then evaporator bottom heater switch ON.  
 When outdoor ambient temperature  $> 2^{\circ}\text{C}$ , or compressor stop, then evaporator bottom heater switch OFF.

## 6.13 reset :

Return to factory paramete setting.

Press  and  at the same time, all the parameter restore initial as long as hear the alarm to display default.

## 6.14 defrosting :

Defrosting has two mode : AUTO, manual. Choose P17 to select defrosting mode :

P17 : defrosting mode : auto defrosting ( 0 ), manual defrosting ( 1 )

### 6.14.1 auto defrosting :

Parameter setting are following :


P18 : defrosting start temperature : range (  $-15^{\circ}\text{C} \sim +2^{\circ}\text{C}$  adjustable ), default is  $-4^{\circ}\text{C}$ .

P21 : defrosting exit temperature : range (  $8^{\circ}\text{C} \sim 20^{\circ}\text{C}$  adjustable ), default is  $12^{\circ}\text{C}$ .

### 1st defrosting start condition ( the first defrosting period is 40 minutes ):

Heat pump first to run, when evaporator temperature  $< 3^{\circ}\text{C}$  continuously for 40 minutes, PCB check if evaporator temperature  $< -4^{\circ}\text{C}$  (parameter 18), then start defrosting.

### During defrosting



Electrical heater switch ON ( switch OFF if water tank temperature  $\geq 65^{\circ}\text{C}$  ), circulation pump run.

### Defrosting exit condition:

When evaporator temperature reach to  $12^{\circ}\text{C}$  (parameter 21), or max defrosting running time = 15 minutes, Defrosting exist.

### next defrosting start condition:

the next defrosting period will be changed according to last defrosting status , the calcaution as following :

Defrosting running time (minutes)	1~2	3~4	5~6	7~8	9~10	11~12	13~15
Defrosting period (minutes)	60	55	50	45	40	35	30

### 6.14.2 manual defrosting :

Parameter setting are following :

- P18 : defrosting start temperature : range ( -15°C ~ +2°C adjustable ), default is -4°C.  
P19 : defrosting period : range (25 ~ 70 minutes adjustable ), default is 30 minutes  
P20 : defrosting time : range ( 2 ~ 20 minutes adjustable ), default is 15 minutes.  
P21 : defrosting exit temperature : range (8°C ~ 20°C adjustable ), default is 12°C.

#### Defrosting start condition:

when evaporator temperature < 3°C continuously for 30 minutes (parameter 19), PCB check if evaporator temperature < -4°C (parameter 18), then start defrosting.

#### Defrosting exit condition:

When evaporator temperature reach to 12°C (parameter 21), or max defrosting running time = 15 minutes (parameter 20), Defrosting exist.

### 6.15 Anti-freeze protection :

Parameter setting : P15 : anti-freeze protection: on ( 1 ), off ( 0 ), default ( 0 ) .

When heat pump is in standby status, PCB check if water tank temperature and ambient temperature are too low.

(1) when 2°C < water tank temperature ≤ 4°C, and ambient temperature ≤ 0°C, then circulation pump run ;

When water tank temperature ≥ 15°C, or ambient temperature > 0°C, exit protection

(2) when water tank temperature ≤ 2°C, and ambient temperature ≤ 0°C, then heat pump run ;

When water tank temperature ≥ 15°C, or ambient temperature > 0°C, exit protection

### 6.16 4-way-valve :

4-way-valve switch ON on heating mode, switch OFF on cooling mode, defrosting.

### 6.17 3-way-water-valve :

3-way-water-valve switch ON on ROOM HEATING/COOLING mode, switch OFF on WATER TANK HEATING, cycle-refrigerant, defrosting. When heat pump stop, 3-way-water-valve switch OFF.

### 6.18 circulation pump:

In WATER TANK HEATING mode, circulation pump stop when water tank temperature reach to setting temperature.

Circulation pump start when water tank temperature drop down, compressor start.

In ROOM HEATING/COOLING mode, circulation pump run all time. And circulation pump stop when error occur.

In floor heating mode, when Outlet water over-heat protection, circulation pump run.

### 6.19 Status checking:

Press  button for 5 seconds to enter status checking,

- do1: frequency  
do2: AD valve of current  
do3: inlet (return) water temperature



d04: water tank temperature  
d05: outlet (feed) water temperature  
d06: room temperature  
d07: compressor exhaust temperature  
d08: outdoor ambient temperature  
d09: evaporator (defrostig) temperature  
d10: NO USE (ground source water inlet temperature)  
d11: NO USE (ground source water outlet temperature)  
d12: step of EEV ( real step = d14\*4)

## 7. Error messages :

Heat pump is equipped with regulation and safety components; when a regulation component is defective or a safety is activated, a message is posted like it's illustrated below; see the explanation of these messages in the paragraph "Error codes". Call your installation contractor for help.

Screen and state of the heat water pump	component
E01	EEPROM read failure from controller or transition circuit board
E02	water tank temperature sensor error
E03	inlet (return ) water temperature sensor error
E04	outlet (feed ) water temperature sensor error
E05	evaporator (defrosting ) temperature sensor error
E06	Outdoor ambient temperature sensor error
E07	Compressor exhaust temperature sensor error
E08	Communication error( controller to transition circuit board)
E09	Communication error( transition circuit board to main circuit board )
E10	Compressor start failure
E11	Current overload error
E12	SPM module alarm
E13	Compressor exhaust over-heat
E14	Water flow switch error
E15	High or low pressure switch error
E16	Room temperature sensor error
E17	Ground source inlet water temperature sensor error
E18	Ground source outlet water temperature sensor error
E19	Compressor return temperature sensor error
E20	Temperature sensor after EEV error

### 7.1 E12 (SPM alarm)


The cause of alarm E12 (SPM alarm) could be:

- 1 The communications between IPM Module and outdoor main circuit board is jamming;
- 2 Module is jamming and can not detect current or compressor;
- 3 Module can not start compressor;
- 4 Module's rated 15VDC voltage is not steady
- 5 Module detect over-currunt protection.

How to do:

1. Please check if all terminals connections among circuit boards are good, whether some of the wire damaged;
2. Please check if the compressor wire connection loose (on the top of compressor);
3. Please measure each two of the connections (on the top of compressor)'s resistance, if the resistance are always the same, means the compressor is fine. there 3 connections on the top of compressor A, B, C , you need to measure each two's resistance :AB, AC, BC;
4. please check wire connection between the outdoor circuit board and module; see the follow picture.
5. Check the DC voltage between terminal P and N if normal, the DC voltage should be:
  - Single phase : 380VDC
  - Three phase : 540VDC

6. check the if DC voltage between + (first wire) and -(third wire) is normal, it should be 13.5V ~16.5V



## 7.2 E09 ( Transition board - main circuit board communicate )

The cause of alarm E9 could be:

1. The connection between transition circuit board and main circuit board is wrong;
2. The connection between transition circuit board and main circuit board is not good, such as had creepage;
3. The transition circuit board or main circuit board was damaged.

How to do

1. Check the connection wire between transition circuit board and main circuit board, their live wires, zero curves was connected correctly;
2. Check the connection wire between transition circuit board and main circuit board, the wire must be less than 20 meters, the terminals must be water- proof;
3. If the connection is fine, then the cause could be the transition circuit board or main circuit board, please check their lights.

## 7.3 module voltage over

The cause of alarm 'MODULE VOLTAGE OVER' could be:

1. Water flow was not enough;
2. One of the sensors got problem;
3. Ambient temperature was too high

How to do:

1. Check if the water flow was not enough;
2. Check all the sensors if they are normal.

## 7.4 CSP protection ( it do not show any error code on display panel)

**Refrigerant system install 2 high pressure protection ( 40bar, 44bar ), 1 low pressure protection ( 0.7bar ).**

**40bar high pressure protection is for CSP protection.**

**(1) When water temperature > 50°C**, compressor stop, circulation pump continuously run, electrical heater switch ON forcibly one time, enter CSP protection. 40bar high protection resume 3 minutes later.

Heat pump will record the highest water temperature, if highest water temperature - water temperature  $\leq 3^{\circ}\text{C}$ , or if water temperature < 50°C, then compressor start, and cancel CSP protection.

**(2) when water temperature < 50°C**, compressor stop, circulation pump continuously run, electrical heater keep previous status ; 3 minutes later, if 40bar high protection resume, then compressor start.

**(3) In water tank heating mode**, heat pump check if water tank temperature match 50°C.

In room heating mode, heat pump check if return water temperature match 50°C.

## **7.5 E13 compressor over-heat**

**The reason of E13 could be:**

- 1. Water flow was not enough;**
- 2. Refrigerant was not enough**
- 3. Ambient temperature was too high;**

**How to do:**

- 1. Check if the water flow was not enough, so that the heat exchange efficiency was not good;**
- 2. Check the refrigerant quantity, and make sure the system has not any leak;**

## **7.6 E14 water flow**

**The reason of E14 could be:**

- 1. Water flow is not enough;**
- 2. The connection of water flow switch was loose or water flow switch was broken;**
- 3. There some air inside the water system, so that the heat exchange area was not enough;**
- 4. The thermostat switch of the electrical heater was broken;**

**How to do:**

- 1. Always ensure enough water flow; otherwise the flow switch can not open;**
- 2. Check the wire connection of water flow switch was normal or not, or replace a water flow switch;**
- 3. Before install the system, please vent the air out from the water system, follow manual's instruction;**
- 4. Measure the thermostat switch of electrical heater by ampere meter.**

## **7.7 E15 low pressure**

**The reason of E15 could be:**

- 1. The refrigerant was not enough ;**
- 2. The connection of low pressure switch was loose, or the switch was broken;**
- 3. The fan can not run**

**How to do:**

- 1. Check if there any place leak refrigerant, especially on the connections valves;**
- 2. Check if the wire connection of low pressure switch was ok, or replace a new low pressure switch;**
- 3. Check if the fan was running, if not, please check if the fan was normal**

## 7.8 high pressure

### The reason of E15 could be:

1. The water flow was not enough;
2. The high pressure switch's connection was not good; or the switch was broken;
3. The ambient temperature was too high.

### How to do:

1. Always ensure enough water flow; otherwise the flow switch can not open;
2. Check if the wire connection of high pressure switch was ok, or replace a new one;

## 7.9 water temperature sensor

1. The connection of water tank temperature sensor was loose;
2. The water tank temperature sensor was broken;

### How to do:

1. Find the connection and make sure it is fine;
2. As per resistance table of the sensor, please measure the sensor's resistance, to judge the sensor was good or bad; replace a new one if the sensor get problem.

## 7.10 feed temperature sensor

1. The connection of feed water temperature sensor was loose;
2. The feed water temperature sensor was broken;

### How to do:

1. Find the connection and make sure it is fine;
2. As per resistance table of the sensor, please measure the sensor's resistance, to judge the sensor was good or bad; replace a new one if the sensor get problem.

## 7.11 return temperature sensor

1. The connection of return water temperature sensor was loose;
2. The return water temperature sensor was broken;

### How to do:

1. Find the connection and make sure it is fine;
2. As per resistance table of the sensor, please measure the sensor's resistance, to judge the sensor was good or bad; replace a new one if the sensor get problem.

## 7.12 evaporator temperature sensor

1. The connection of pipe temperature sensor (on evaporator, for defrosting) was loose;
2. The pipe temperature sensor was broken;

### How to do:

1. Find the connection and make sure it is fine;

2. As per resistance table of the sensor, please measure the sensor's resistance, to judge the sensor was good or bad; replace a new one if the sensor get problem.

### **7.13 outdoor ambient temperature sensor**

1. The connection of outdoor ambient temperature sensor was loose;
2. The outdoor ambient temperature sensor was broken;

**How to do:**

1. Find the connection and make sure it is fine;
2. As per resistance table of the sensor, please measure the sensor's resistance, to judge the sensor was good or bad; replace a new one if the sensor get problem.

### **7.14 compressor exhaust temperature sensor**

1. The connection of compressor exhaust air temperature sensor was loose;
2. The compressor exhaust air temperature sensor was broken;

**How to do:**

1. Find the connection and make sure it is fine;
2. As per resistance table of the sensor, please measure the sensor's resistance, to judge the sensor was good or bad; replace a new one if the sensor get problem.





**\* wiring diagram for 230-50Hz-1phase**

# 9. temperature sensor resistance table :

## 9.1 compressor exhaust temperature sensor resistance t °c -- kΩ 50 k

t °c	R(KΩ)	AD	t °c	R(KΩ)	AD	t °c	R(KΩ)	AD	t °c	R(KΩ)	AD
-20	542.7	3	20	68.66	26	60	13.59	95	100	3.702	175
-19	511.9	3	21	65.62	28	61	13.11	97	101	3.595	177
-18	483	4	22	62.73	29	62	12.65	99	102	3.492	178
-17	455.9	4	23	59.98	30	63	12.21	101	103	3.392	180
-16	430.5	4	24	57.37	31	64	11.79	103	104	3.296	181
-15	406.7	4	25	54.89	32	65	11.38	106	105	3.203	183
-14	384.3	5	26	52.53	34	66	10.99	108	106	3.113	184
-13	363.3	5	27	50.28	35	67	10.61	110	107	3.025	186
-12	343.6	5	28	48.14	36	68	10.25	112	108	2.941	187
-11	325.1	6	29	46.11	38	69	9.902	114	109	2.86	188
-10	307.7	6	30	44.17	39	70	9.569	117	110	2.781	190
-9	291.3	6	31	42.33	40	71	9.248	119	111	2.704	191
-8	275.9	7	32	40.57	42	72	8.94	121	112	2.63	193
-7	261.4	7	33	38.89	43	73	8.643	123	113	2.559	194
-6	247.8	8	34	37.3	45	74	8.358	125	114	2.489	195
-5	234.9	8	35	35.78	47	75	8.084	127	115	2.422	196
-4	222.8	8	36	34.32	48	76	7.82	129	116	2.357	198
-3	211.4	9	37	32.94	50	77	7.566	132	117	2.294	199
-2	200.7	9	38	31.62	52	78	7.321	134	118	2.233	200
-1	190.5	10	39	30.36	53	79	7.086	136	119	2.174	201
0	180.9	10	40	29.15	55	80	6.859	138	120	2.117	202
1	171.9	11	41	28	57	81	6.641	140	121	2.061	203
2	163.3	12	42	26.9	59	82	6.43	142	122	2.007	204
3	155.2	12	43	25.86	60	83	6.228	144	123	1.955	206
4	147.6	13	44	24.85	62	84	6.033	146	124	1.905	207
5	140.4	13	45	23.89	64	85	5.844	148	125	1.856	208
6	133.5	14	46	22.89	66	86	5.663	150	126	1.808	209
7	127.1	15	47	22.1	68	87	5.488	152	127	1.762	210
8	121	15	48	21.26	70	88	5.32	154	128	1.717	211
9	115.2	16	49	20.46	72	89	5.157	156	129	1.674	211
10	109.8	17	50	19.69	74	90	5	157	130	1.632	212
11	104.6	18	51	18.96	76	91	4.849	159			256
12	99.69	19	52	18.26	78	92	4.703	161			256
13	95.05	20	53	17.58	80	93	4.562	163	B(25/50) = 3950K ± 3% R(90°C) = 5KΩ ± 3%		256
14	90.66	20	54	16.94	82	94	4.426	165			256
15	86.49	21	55	16.32	84	95	4.294	167			256
16	82.54	22	56	15.73	86	96	4.167	168			256
17	78.79	23	57	15.16	88	97	4.045	170			256
18	75.24	24	58	14.62	90	98	3.927	172			256
19	71.86	25	59	14.09	93	99	3.812	173			256

## 9.2 water/ambient/evaporator temperature sensor resistance $t^{\circ}\text{C} - \text{k}\Omega$ 10 k

$t^{\circ}\text{C}$	R(K $\Omega$ )	AD	$t^{\circ}\text{C}$	R(K $\Omega$ )	AD	$t^{\circ}\text{C}$	R(K $\Omega$ )	AD	$t^{\circ}\text{C}$	R(K $\Omega$ )	AD
-20	115.266	16	20	12.6431	99	60	2.35774	197	100	0.62973	236
-19	108.146	17	21	12.0561	102	61	2.27249	198	101	0.61148	237
-18	101.517	18	22	11.5	105	62	2.19073	200	102	0.59386	237
-17	96.3423	19	23	10.9731	107	63	2.11241	202	103	0.57683	237
-16	89.5865	21	24	10.4736	110	64	2.03732	203	104	0.56038	238
-15	84.219	22	25	10	113	65	1.96532	205	105	0.54448	238
-14	79.311	23	26	9.55074	116	66	1.89627	206	106	0.52912	239
-13	74.536	24	27	9.12445	119	67	1.83003	207	107	0.51426	239
-12	70.1698	26	28	8.71983	122	68	1.76647	209	108	0.49989	240
-11	66.0898	27	29	8.33566	125	69	1.70547	210	109	0.486	240
-10	62.2756	29	30	7.97078	128	70	1.64691	211	110	0.47256	240
-9	58.7079	30	31	7.62411	131	71	1.59068	212	111	0.45957	241
-8	56.3694	31	32	7.29464	133	72	1.53668	214	112	0.44699	241
-7	52.2438	34	33	6.98142	136	73	1.48481	215	113	0.43482	241
-6	49.3161	35	34	6.68355	139	74	1.43498	216	114	0.42304	242
-5	46.5725	37	35	6.40021	142	75	1.38703	217	115	0.41164	242
-4	44	39	36	6.13059	144	76	1.34105	218	116	0.4006	242
-3	41.5878	41	37	5.87359	147	77	1.29078	219	117	0.38991	243
-2	39.8239	42	38	5.62961	150	78	1.25423	220	118	0.37956	243
-1	37.1988	45	39	5.39689	152	79	1.2133	221	119	0.36954	243
0	35.2024	47	40	5.17519	155	80	1.17393	222	120	0.35982	244
1	33.3269	49	41	4.96392	157	81	1.13604	223	121	0.35042	244
2	31.5635	51	42	4.76253	160	82	1.09958	224	122	0.3413	244
3	29.9058	54	43	4.5705	162	83	1.06448	225	123	0.33246	244
4	28.3459	56	44	4.38736	165	84	1.03069	226	124	0.3239	245
5	26.8778	58	45	4.21263	167	85	0.99815	226	125	0.31559	245
6	25.4954	61	46	4.04589	169	86	0.96681	227	126	0.30754	245
7	24.1932	63	47	3.88673	172	87	0.93662	228	127	0.29974	245
8	22.5662	67	48	3.73476	174	88	0.90753	229	128	0.29216	246
9	21.8094	68	49	3.58962	176	89	0.8795	229	129	0.28482	246
10	20.7184	71	50	3.45097	178	90	0.85248	230	130	0.2777	246
11	19.6891	74	51	3.31847	180	91	0.82643	231	131	0.27078	246
12	18.7177	76	52	3.19183	182	92	0.80132	231	132	0.26408	246
13	17.8005	79	53	3.07075	184	93	0.77709	232	133	0.25757	247
14	16.9341	82	54	2.95896	186	94	0.75373	233	134	0.25125	247
15	16.1156	85	55	2.84421	188	95	0.73119	233	135	0.24512	247
16	15.3418	87	56	2.73823	190	96	0.70944	234	136	0.23916	247
17	14.6181	90	57	2.63682	192	97	0.68844	234	137	0.23338	247
18	13.918	93	58	2.53973	193	98	0.66818	235	138	0.22776	247
19	13.2631	96	59	2.44677	195	99	0.64862	236	139	0.22231	248

# 11 Specification

	50	70	90	120	150	180
Power Supply	230V - 1Phase - 50Hz: L, N, earth			380V - 3Phase - 50Hz: R,S,T,N,earth		

Performance							
Heating Capacity at A7/W35	kW	5	7	10	13	15	18
C.O.P.	W/W	4.1	4.1	4.1	4.1	4.1	4.1
Power input	kW	1.2	1.7	2.4	3.2	3.7	4.4
Startup current	A	1.5	1.5	1.5	2.5	2.5	2.5
Running current		5.5	7.8	11.1	5.5	6.3	7.6

Features							
Controls		Microprocessor					
Fan speeds		1 speed					
Operation noise level	dB(A)	52	55	58	60	62	62
Ambient/water/evaporator temp. sensor	kΩ	10k(25°C)					
Compressor exhaust temp. sensor	kΩ	50k(25°C)					
Refrigerant		R410a					
Refrigerant control		electronic expansion valve					

Compressor							
DC inverter compressor		Twin rotary					scroll
Coil resistance (Ambient temp. 25°C)	Ω	R-S:					
	Ω	S-T:					
	Ω	T-R:					
Safety devices	* CT ( Peak current cut-off control )	yes					
	* compressor discharge temp. control	yes					
	* high refrigerant pressure protection	yes					
	* low refrigerant pressure protection	yes					
	* CSP pressure protection	yes					
crankcase heater		30W, 240V					

Fan * Fan Motor							
Fan type		propeller					
quantity ... Diameter	mm	1 ... Ø420	1 ... Ø450	1 ... Ø490	2 ... Ø420	2 ... Ø490	2 ... Ø490
No. of poles ... rpm 220V		4 ... 670	4 ... 670	6 ... 670	4 ... 670	6 ... 670	6 ... 670
nominal output	W						
run capacitor		2uF	2uF	5uF	2uF	5uF	5uF
		440WAC	440WAC	440WAC	440WAC	440WAC	440WAC

evaporator							
coil	aluminum plate fin / inner-grooved copper tube						
rows	3						
pin pitch	mm	2.2					
face area	m <sup>2</sup>						

heat exchanger							
type	shell tube						

Hydraulic module							
return water connection	inch	3/4					
outlet water connection to house	inch	3/4					
outlet water connection to water tank	inch	3/4					
max pressure in water tank	bar	7					
max pressure in spiral copper pipe	bar	4					
circulation pump	speed	3					

electrical heater							
type	sheath						
material	stainless steel						
operation	automatic						
step	1						
capacity	kW	3					
power supply	230/50/1						

Dimensions & Weight							
	height	mm					
	width	mm					
	depth	mm					
	weight	kg					